```
                    SETUP PROGRAM
                    TANDY 4020 LX

| Date & Time          | Memory              | Video & CPU          |
|----------------------|---------------------|----------------------|
| Date [11/09/1990]    | Base      [  640K]  | Video [VGA or EGA]   |
| Time [09:15:25]      | Extended  [ 1024K]  | CPU speed [Fast  ]   |
|                      | Total   =   1664K   |                      |
| Hard Drives          | Floppy Drives       | Options              |
|                      | A: [1.44M 3.5-inch] | Serial port [Disabled  ] |
| C:  [ 40Meg-Type17 ] | B: [360K 5.25-inch] | Parallel port [Disabled] |
| D:  [ None         ] | Startup Floppy [A:] | Bidirectional [N]    |
| SmartDrive installed [Y] | Controller [Enabled ] | Mouse [Disabled]     |

<ESC> Exit to DOS without saving setup    <CTRL_BRK> Reboot without saving
<F1> Help for option that cursor is on        <SPACE> Toggles options
<F2> Save setup and exit                      <ARROW> Moves to next option
```

TYPE	HEAD	CYLINDER	PRECOMP	PARK	SECTORS	SIZE(Megabytes)
SCSI						
ESDI						
None						
1	4	306	128	305	17	10
2	4	615	300	615	17	20
3	6	615	300	615	17	30
4	8	940	512	940	17	62
5	6	940	512	940	17	46
6	4	615	None	615	17	20
7	8	462	256	511	17	30
8	5	733	None	733	17	30
9	15	900	None	901	17	112
10	3	820	None	820	17	20
11	5	855	None	855	17	35
12	7	855	None	855	17	49

```
<  □  > Next Line                      <  □  >  Previous Line
<PgDn > Next Page                      <PgUp >  Previous Page
<ENTER> Update and Return to Main Screen
< ESC > Return to Main Screen Without Updating
< F1  >  Help
```

TYPE	HEAD	CYLINDER	PRECOMP	PARK	SECTORS	SIZE(Megabytes)
13	8	306	128	319	17	20
14	7	733	None	733	17	42
15						
16	4	612	0	663	17	20
17	5	977	300	977	17	40
18	7	977	None	977	17	56

19	7	1024	512	1023	17	59
20	5	733	300	732	17	30
21	7	733	300	732	17	42
22	5	733	300	733	17	30
23	4	306	0	336	17	10
24						
25	4	615	0	615	17	20
26	4	1024	None	1023	17	34
27	5	1024	None	1023	17	42

< □ > Next Line < □ > Previous Line
<PgDn > Next Page <PgUp > Previous Page
<ENTER> Update and Return to Main Screen
< ESC > Return to Main Screen Without Updating
< F1 > Help

TYPE	HEAD	CYLINDER	PRECOMP	PARK	SECTORS	SIZE(Megabytes)
28	10	981	None	980	17	81
29	8	512	256	512	17	34
30						
31						
32						
33						
34						
35	9	1023	None	1023	17	76
36	10	1024	1023	1023	17	85
37	5	989	128	989	17	41
38	5	1024	1024	1024	17	42
39	6	820	820	820	17	40
40	8	1024	1024	1024	17	68
41	6	306	153	306	17	15
Any	(Non Standard Hard Disk)					

< □ > Next Line < □ > Previous Line
<PgDn > Next Page <PgUp > Previous Page
<ENTER> Update and Return to Main Screen
< ESC > Return to Main Screen Without Updating
< F1 > Help

Non Standard Hard Disk Drive

Heads [0]
Cylinders [0]
Precompensation
Cylinder # or 'NONE' [0]
Head Landing Zone [0]
Sectors Per Track [0]

Enter the above information from
your hard drive users manual.

< ESC > Return to Selection Screen
<ENTER> Complete One Entry