

## IGNORED CONTROL CODES

ALL MODES:

\* Redundant codes that don't change the current Printer status. For example, if you send a 27 17 sequence when Elongation has already been set.

CP MODE: 0,1,127,255,30

GRAPHICS MODE: All codes in the range 0-127 except LF,CR,27 14,27 15,27 50, and 30.

## CODES PRINTED AS X

CP MODE: All codes from 0-31 and 128-159, except the active function codes or the above ignored codes.

DEC. HEX.		CHARACTER PRINTING MODE	GRAPHICS MODE	REMARKS
00	00	Ignored	Ignored	
01	01			
10	0A	Full Line Feed (Executive)	7/72" Line Feed (Executive)..... 8A hex. 138 dec.	
138	8A			
13	0D	Carriage Return (When LF pitch is 1/6" per Line)	Carriage Return only. 0D hex. When NL,LF pitch is 7/72")	NL/CR code selectable
141	8D			
014	0E	End Underline	Ignored	
015	0F	Start Underline	Ignored	
18	12	Select Graphics Mode	Ignored	
27	1B	Start Elongation	Start Elongation	
14	0E			
27	1B	End Elongation	End Elongation	
15	0F			
27	1B	Select Standard Character	Ignored	
19	13			
27	1B	Select Condensed Character	Ignored	
20	14			
27	1B	Half Forward Line Feed (Latched only)	Ignored	
28	1C			
27	1B	Start Bold	Ignored	

31	1F			
27	1B	1/12 Forward	Ignored	
50	32	Line Feed		
27	1B	Full Forward Line	Ignored	
54	36	Feed (Latched only)		
27	1B	Set 3/4 Forward	Ignored	
56	38	Line Feed (No motion)		
30	1E	Ignored	End Graphic Mode	
127	7F	Ignored	Ignored	
255	FF	Ignored	(Printing data)	
Other Codes in Function Area (02 to 31 dec) (02 to 1F hex)		Prints "X" marks	Ignored	
Other Codes in Function Area (128- 159, 80 to 9F hex)		Prints "X" marks	(Printing Data)	

(abo-07/26/93)

□