


SECOND On Off Off Off On Off Off Off Off Off Off Off
INTERNAL HD

SETTING UP THE ST225 DRIVE

Check the position of the jumper on the back edge of the PCB on the bottom of the hard disk drive (see Figure 2) to be sure the jumper is set to the desired position.



FIRST	1	3	5	6	9	11	13	15	Terminal Resistor Installed
INTERNAL HD	2	4	6	8	10	12	14	16	
SECOND	1	3	5	6	9	11	13	15	Terminal Resistor Removed
INTERNAL HD	2	4	6	8	10	12	14	16	
	Radial	Write	Life	DS4	DS3	DS2	DS1		
	Recovery	Test	Test						
	Mode								

When installing a Seagate drive as the second hard disk drive the termination resistor should be removed from the drive prior to installation.

(css 07/29/93)