



#### Contrast and Brightness:

Use these controls to adjust the screen brightness to compensate for room lighting. Rotate either or both controls clockwise to increase brightness; rotate counterclockwise to decrease brightness.

The contrast control is also used to adjust color brilliance - low or high as needed. The brightness control has a slight "catch" at its center position; in most situations you'll be able to leave it at this "normal" setting.

#### Power ON/OFF

To turn on the VGM-300, press POWER. The POWER indicator lights. Press POWER again to turn off the monitor.

#### Vertical Size 1:

Use this control to adjust the vertical size of the display for Mode 3.

#### Vertical Size 2:

Use this control to adjust the vertical size of the display for Mode 1.

#### Vertical Size 3:

Use this control to adjust the vertical size of the display for Mode 2.