


**MODEL 18 VIDEO CASSETTE
RECORDER MOVING MECHANISM I
SHEET # 1 (160-0507)
FAXBACK DOC # 10670**



MODEL 18 VIDEO CASSETTE
RECORDER MOVING MECHANISM I
SHEET # 2 (160-0507)
FAXBACK DOC # 10670

