

JUMPER OPTIONS

A set of three pins is designed to customize the board to your phone system. If you use a standard home phone, place the jumper over pins E4 and E5. If you have a multi-line business phone, use pins E5 and E6.

SETTINGS	
Standard Home Phone	E4 and E5
Multi-line Business Phone	E5 and E6

The modem board has a built-in provision for configuring it to match your requirements. It can be matched for use with an external RS-232, a single-line (home type) telephone connection, or the typical multi-line business installation.

On the board are two groups of electrical jumpers. A jumper is a small rectangular block of black plastic which has two openings in its base. When it is placed over two metal pins which extend about 1/4 " above the surface of the board, it electrically connects those pins together.

One set of three pins are labeled PRIMary and SECondary. As supplied, the modem option board comes configured for the primary mode. If you plan to use only the modem option board, you may skip to the installation instruction page. However, if you already have installed, or plan to immediately install the separate RS-232C option board, remove the jumper from the center pin and the pin marked PRI and, instead, place the jumper over the center pin and the one marked SEC.

Another set of three pins are designed to customize the board to your phone system. If you use a standard home phone, place the jumper over pin E4 and E5. If you have a multi-line business phone, use pins E5 and E6.

(abo-07/28/93)

